

Abt4592




Radius Gauge - Method of Use

Use gauge to determine radii of less than 6.0mm; especially on switch rail tips.

Hold gauge, edge 'A', flat to running face of rail and lower until top face/radius makes contact.

Contact in area 'B' indicates radius more than 6mm.

Contact in area 'C' indicates radius less than 6mm.



Abtus Ltd, Falconer Road, Haverhill, CB9 7XU, UK
+44(0)1440 702938 www.abtus.com